

BLAUPUNKT

BLAUPUNKT
Brand
established
1924
GERMANY

Full HD
1080

12V/24V
DIGITAL VIDEO RECORDER
BP 3.1 A



Enjoy it.

Operating and Installation Instructions


CAUTIONS

- Please insert the micro SD card in the right direction to avoid damage to the card or the device. If device shows error message, please format the micro SD card from device menu. Please reset device or change micro SD card if similar error continues.
- Please operate the product within the temperature of $-20^{\circ}\text{C} \sim 80^{\circ}\text{C}$. Continuous exposure to sunlight, especially when locked in cabin where temperature exceeds 80°C may result to device malfunction, colour change, housing and image distortion.

Note : All files will be deleted when formatting micro SD card or firmware update, please backup the important files prior to that. When reset function is selected, the device will return to default setting.

- Assign mounting location that will not obstruct driver in any circumstances. Or cause injuries to drivers and passengers in case of emergency brake or accident.
- Blaupunkt does not warrant the performance of device if used with other Micro SD card other than Blaupunkt Micro SD card
- New Micro SD card must be formatted for first use. Micro SD must be formatted once every 6-month.
- Ensure bracket is installed correctly & firmly on windscreen to avoid damage to device and for better recording angle.
- Please do not use product under wet environment as device is not waterproofed/ water resistant.
- Please do not record or take picture facing sunlight.
- To obtain clear image, please clean windscreen and device lens regularly. Avoid using device in dusty environment.
- Handle device with care and avoid direct impact on the device. Avoid using device in high electromagnetic environment.
- In no event shall Blaupunkt be liable for any direct, indirect, punitive, incidental, special consequent, damages, to property or life, improper storage, whatsoever arising out of or connected with the use or misuse of our products.
- USA & CANADA : Products not intended for sales in the United States and Canada. If purchased in the U.S. or Canada, this product is purchased as-is. No warranty, expressed or implied is provided in the U.S. and Canada.
- This device is NOT intended to be used for illegal purpose, surveillance and shall not be used in any form as evidence for claim purposes.
- Some countries prohibit drivers from mounting anything on the windshield, or restrict mounting to specific areas of the windshield. It is the owner's responsibility to mount the device in compliance with local laws.
- Error may occur depending on the surrounding environment and the voltage of the car.
- Blaupunkt is not liable/responsible for non-recorded event, missing files, etc.

STRUCTURE



1. 12V-24V mini USB power supply
2. Reset
3. Power
 - Press once to turn on
 - Press once to turn off (at standby mode)
4. Recording indicator light
 - Flashes when recording
5. Menu / SOS
 - Work as SOS during recording
 - Enter into Menu at standby mode
6. Up
7. Down / Voice recording shortcut-key
 - Mute & unmute during recording
8. Mode / Record / Stop record
 - Press to recording or stop record
 - Press, hold & release to switch between Video - Photo - Playback mode
 - Press to select Menu option
9. Micro SD card slot
 - Support up to 64gb Class 10 microSD
10. Microphone
11. Start / Stop recording
12. Bracket slot
13. Speaker
14. Lens

Features

- Resolution : 2MP FHD 1920 x 1080 30 fps
- Wide viewing angle : 140°
- Mode : Video, camera, playback
- 2" LCD display
- Wireless app control available at App Store & Play Store
- G-sensor, loop recording
- Built-in microphone & speaker
- Language : English, Chinese Simplified, Chinese Traditional, Japanese, Thailand
- Night vision supported by WDR & HDR
- Super capacitor technology
- Support up to 64GB microSD Class 10

FUNCTIONS - APP


Pair DVR with Android Smartphone

The distance range between the DVR and smartphone is approximately 10 meters (33ft) in an open field environment.

Wireless Connection (Wi-Fi)

Enable Wi-Fi on Smartphone before beginning (Refer to the instruction manual of the smartphone on how to operate Wi-Fi)

- Ensure to download **Blaupunkt DVR BP3.1A** from App Store (iOS) or Play Store (Android).
- At standby mode, press **5** (Menu) twice then select **Wi-Fi** to turn on.



- Go to smartphone Wi-Fi connection setting, search for BP3.1A, then key-in password **12345678**

- BP3.1A will indicated successful connection when connected
- Open the BP3.1A app from your smartphone, and select **Connect to device**.



- App will began recording automatically when BP3.1A is connected.

Repeat Wireless Connection steps whenever smartphone is disconnected

Download Video or Photo

- Go to app recording screen to select Video or Photo gallery.




Video



Photo

- Press and hold preferred video/photo to select then press **↓** to download file.




FUNCTIONS - DVR


Car Plate Number

- At standby mode, press **5** (Menu) twice then select **Car No**
- Press **8** (Mode) to change digit location.
- Press, hold & release **8** to switch between Alphabet and Numeric.
- Press **5** (Menu) when complete to exit the setting.

Emergency Recording

- The device begins saving recording when the assigned sensitivity intensity is detected.  will appear on the LCD display. Video file (file size based set loop recording) will be saved under Emergency file.
Adjust sensitivity in *Menu > G-sensor*

SOS (Manual Mode)

- During recording, press **5** (Menu) to manually save file as Emergency file.  will appear on the LCD display. Video file (file size based set loop recording) will be saved under Emergency file.

Auto Power Off

- The device will automatically shut down if microSD card is not inserted within the set time.




Super Capacitor Technology

- This technology ensure video files are saved even if sudden power cut-off.

FUNCTIONS

Setting	WiFi	ON/OFF
	Date/Time	YY/MM/DD, MM/DD/YY, DD/MM/YY
	Auto Power Off	Off/1-min/3-min/5-min
	Beep Sound	ON/OFF
	Language	English, Chinese Simplified, Chinese Traditional, Japanese, Thailand
	Car NO	10-alphanumeric
	Screensavers	Off/30-sec/1-min/2-min
	Frequency	50Hz/60Hz
	Format	All data will be deleted. Backup data to prevent unwanted files from being deleted
	Default setting	Restore setting to default setting
	Version	BP3.1A version
Video	Resolution	1080P 1920x1080 30FPS
		720P 1280x720 30FPS
		VGA 640x480 30FPS
	Loop Recording	Off/1-min/3-min/5-min
	HDR	ON/OFF
	Exposure	-2.0, -5/3, -4/3, -1.0, -2/3, -1/3, 0, 1/3, 2/3, 1, 4/3, 5/3, 2
	Record Audio	ON/OFF
	Date Stamp	ON/OFF
G-sensor	Off/Low/Medium/High	
Image	Capture Mode	Single/2s Timer/5s Timer/10s Timer
	Resolution	12M/10M/8M/5M/3M/2MGD/VGA/1.3M
	Sequence	ON/OFF
	Quality	Fine/Normal/Economy
	Sharpness	Strong/Normal/Soft
	White Balance	Auto/Daylight/Cloudy/Tungsten/Fluorescent
	Color	Color/Black&White/Sepia
	ISO	Auto/100/200/400
	Exposure	-2.0, -5/3, -4/3, -1.0, -2/3, -1/3, 0, 1/3, 2/3, 1, 4/3, 5/3, 2
	Anti-shaking	ON/OFF
	Quick Review	Off/2-sec/5-sec
Date Stamp	Off/Date/Date&Time	
Playback	Delete/Protect/Slideshow	

ACCESSORIES



*Subject to change

